



## Drop-in Closing Panel Installation Instructions



Install channel on inside of building  
Photo 1

Closing panel is **installed on the inside** of building or door.

1. Construct a 2" wide frame on inside mounting surface.
2. Place channel angle one inch from dog door cut opening.
3. Install screw at base of each channel.
4. Slide heavy-duty closure into channel. Remove as needed.
5. Drill a finger-hole or install a cabinet knob on top section of closing panel.



An installed closure on metal door  
Photo 2

[BACK TO TOP](#)

[Print This!](#)

Categories : [Instructions](#)