

Drop-in Closing Panel Installation Instructions



Install channel on inside of building
Photo 1

Closing panel is installed on the inside of building or door.

- 1. Construct a 2" wide frame on inside mounting surface.
- 2. Place channel angle one inch from dog door cut opening.
- 3. Install screw at base of each channel.
- 4. Slide heavy-duty closure into channel. Remove as needed.
- 5. Drill a finger-hole or install a cabinet knob on top section of closing panel.



An installed closure on metal door Photo 2



1350 Chester Industrial Pkwy Avon, OH. 44011 gundoghousedoor@gmail.com 1-888-442-2214