



## PVC Wall Trim Kit Installation Instructions



This dog door wall trim kit is designed to install on wall thicknesses of 4" to 8"

**Before beginning, check that you have all included parts.**

(PVC Wall Trim Kit contains 1-inside trim frame, 1-outside trim frame, eight 1-5/8" phillips head screws. Optional: foam tape weather stripping (purchased locally))

- Place PVC Wall Trim Kit on the mounting surface at the desired location and **draw a cutting template**. Double check that the dimensions are 13-1/4" wide and 18-1/4" high.
- **Cut out the opening**. If there is outside lapped siding, we suggest trimming it back two inches to create a flat mounting surface.
- **Lay a caulk bead** around inside and outside surface along the edge of the cut opening.
- **First press the inside trim piece** onto the caulk bead on the inside of the wall, **then place the outside trim piece** on the outside of the wall—sandwiching the wall between the trim pieces.
- **Screw the inside and outside** Trim Kit pieces to the wall.
- **Place the foam tape weather stripping** onto the outside trim kit frame along the left, right and bottom edges.
- **Mount the dog door** to the outside trim kit frame with the two screws provided with the door. (See installation tips)

[Print This!](#)

Categories : [Instructions](#)

Tags : [trim kit](#)