



[Home](#) » [Instructions](#) » PVC Trim Kit for a Door Installation Instructions

PVC Trim Kit for a Door Installation Instructions



This trim kit is designed for door thicknesses of 1-1/4" to 2"

Before beginning, check that you have all included parts. (The PVC Door Trim Kit contains 1- inside trim frame, 1- outside trim frame, eight 1-5/8" Phillips head screws.) Optional: foam tape weather stripping (purchased locally)

- Place PVC Trim Kit on door at the desired location and **draw a cutting template**. Double check that the dimensions are 13-1/4" wide and 18-1/4" high.
- **Cut out the opening.**
- **Lay a caulk bead** around inside and outside surface along the edge of the cut opening.
- **First press the inside trim piece** onto the caulk bead on the inside of the door, **then place the outside trim piece** on the outside of the door—sandwiching the door between the trim pieces.
- **Screw the Trim Kit pieces** to the inside and outside of the door.
- **Place the foam tape** weather stripping onto the outside trim kit frame along the left, right and bottom edges.
- **Mount the dog door** to the outside trim kit frame with the two screws provided with the door. (See installation tips)



Installed Steel Door
Trim Kit

[Print This!](#)

Categories : [Instructions](#)

Tags : [trim kit](#)

Gun Dog House Door® INC
Better Dog Doors & Pet Doors

1-800-789-0203 • 701-354-7700 • Fax 701-354-0117
13835 34th St NW • Bismarck, ND 58503
International 701-354-7700

© Copyright 1992-2017 All Rights Reserved Gun Dog House Door® Inc.